



www.spapool.co.nz
info@spapool.co.nz

The Plug In Spa Limited
Trading as Spa International
7 Industry Rd, Penrose
Auckland
0800 SPAPOOL (0800 772 766)

FAQs – Maintenance

What maintenance is required?

- **Water:** Monitor the water for water purification no less than once a week and adjust as required. Change the water about every six to eight weeks.
- **Filter:** Clean the water filter under a hose every two to three weeks. Soak the filter in a filter cleaning solution three to four times per year. Renew the filter every twelve months.
- **Cedar surround:** Oil at least twice a year with an oil based wood preservative.
- **Lockable cover:** Clean periodically with a vinyl cleaner or protectant. Check locks periodically to ensure they are functioning.
- **Spa pump & associated equipment:** Check the pump bay periodically to ensure that water is not dripping from any joint or any part of the pump.

How much will it cost to run Plug 'n Spa pool?

Typically the plug 'n spa will cost about \$6.00 per week in electricity charges. This will vary according to the electricity unit charge and ambient temperature. See our website page “Heating costs” for a detailed discussion.

How often do I need to change the water?

As a guide, the water should be changed about every eight weeks. This is only a guide; the time is influenced by frequency of use, the persons using the spa and vigilance in maintenance.

How do I empty the water?

Connect a garden hose to the exit valve found within the pump compartment.